™ MICROBAC®	80 Run Way, Lee, MA 01238	413.776.5025 p

CHAIN OF CUSTODY RECORD

Number

														11 13	structioi	15 011 0	ack	
Lab Report Address			Invoice Address					Turnaround Time					TC	TO BE COMPLETED BY MICROBAC				
Client Name:		Client Name:				☐ Routine (5 to 7 business days) ☐ RUSH* (notify lab)						Temperature Upon Receipt (°C) Therm ID						
Address:			Address:												Holding Time			
City, State, Zip:			City, State, Zip:				(needed by)					Sa	Samples Received on Ice? ☐ Yes ☐ No ☐ N/A					
Contact:			Contact:						Report Type					Cu	Custody Seals Intact? ☐ Yes ☐ No ☐ N/A			
Telephone N	lo.:		Telephone No	.:					☐ Result	s Only		evel 1	Leve	el 2 🛭] Level :	3 □L	evel 4 🔲 EDD	
Send Report	: via:	address)					Send Inv	voice via:	☐ Mail [Fax	□ e-	mail (a	address)					
Project:			Location: PO No.:				Compliance Monitoring? ☐ Yes ☐ No ☐ Agency/Program											
Sampled by (PRINT):			Sampler Signature:				Sampler Phone No.:											
**	* Matrix Types: Soil/Solid (S), Slud Preservative Types: (1) HNO3, (2) H2		•	. , ,			. ,,	,			•			- /	II) IInpr	eserve	4	
	Treservative Types. (1) Tiltes, (2) Til	00 1, (0) 1101, (T) Naori, (3) Zine Acetate, (0) Methanol, (7) Sociali Bisu									IALYSIS	чино, (o) onpr	0001 700	u .		
Lab ID	Client Sample ID	Date Collected	Time Collected	No. of Containers	Matrix	Grab / Comp	Preservative Types **										Additional N	lotes
	zard Identification	ous 🗌 Non-Ha	zardous 🗌 Ra	adioact	ive			Sample Di	sposition		Dispose	as ap	propriate	e 🗌 F	Return	☐ Arch	nive	
Comments		Relinquished By (signature) Date/Time			ïme	Received By (signature				re)) Date/Time							
		Relinquished By (signature) Date/Tim			ïme	Received By (signatu				(signatu	re)			Date/Time				
		Relinquished By (signature) Date/Time		ïme	Received By (signature)					Date/Time								

rev. 7/18/18

Page of

Sample Acceptance Policy for Environmental Chemistry and Microbiology

Chain of Custody

A chain of custody MUST accompany all samples received at the laboratory. The following information on the Chain of Custody must be complete: client name and address, sample collector's name, sample description/identification, matrix, date and time of collection, number of containers, preservative and requested analysis. Any missing receipt information will be documented in the final report. The laboratory will analyze those target analyses identified by the client on a project-specific basis. If project-specific information is not available, then the laboratory's default reference methods and target list of analyses will be used.

Sample Containers

Upon receipt at the laboratory sample containers will be evaluated to ensure that all of the containers are intact, that the container type meets the requirement of the specific analytical method, and that the Sample Containers are properly filled.

Preservatives

Chemical preservatives are required by many analytical methods in order to render a specific analyte stable until analysis can be performed at the laboratory. Chemical preservatives are to be added AT THE TIME OF SAMPLING (either added directly or via pre-preserved bottles), unless it is unsafe to do so.

Transport/Receipt Temperature

Many of the analytical methods utilized require that samples be kept cool during sample transport. Microbac will assess and document the receipt temperature of each cooler received at the laboratory. Where thermal preservation is required, the receipt temperature must be in a range of $0.1 - 6^{\circ}$ C for environmental chemistry samples or <10 $^{\circ}$ C for environmental microbiology samples. Samples received on the same day as collection will be measured for temperature but will be evaluated based on the sample transport conditions. Samples delivered on the same calendar day as collection must be presented to the lab such that an attempt has been made to cool the samples, such as storage in a cooler on ice.

Holding Time

Samples should be provided to the laboratory as soon as possible after collection to ensure that analysis can be performed within the method specified Holding Time. Upon receipt at the laboratory, the sample date and time as well as the required chemistries will be evaluated to identify if any of the samples may be past the maximum holding time.

If it is determined that a container or sample condition has been compromised, is inappropriate for the requested analysis, improperly filled, improperly preserved or received outside of the required temperature range or received with inadequate holding time available, your Microbac Project Manager will contact you for direction. Documentation of decisions made to proceed with analysis will be provided to you as part of the Cooler Inspection form in the final report.

In the absence of a written agreement to the contrary, by delivering or arranging for delivery of samples to the lab, the customer agrees to our standard terms and conditions which can be found at https://www.microbac.com/standard-terms-conditions.