

EPA 1633 PFAS SAMPLE COLLECTION GUIDE

NON-DRINKING WATER

The following instructions are provided by Microbac Laboratories as guidance for the collection of water samples for PFAS analysis by EPA Method 1633. Collection procedures are outlined in EPA Method 1633 “Analysis of Per- and Polyfluoroalkyl Substances (PFAS) in Aqueous, Solid, Biosolids, and Tissue Samples by LC-MS/MS” and should be reviewed by persons responsible for collecting samples.



SAMPLING PRECAUTIONS

- Avoid wearing clothing or boots containing Gore-Tex or materials made with Tyvek.
- Avoid using fabric softeners on clothing to be worn in the field.
- Avoid using cosmetics, moisturizers, sunscreens and insect repellants on the day of sampling.
- Do not use felt-tip pens, permanent markers or Sharpies. Only regular ball point pens are acceptable.
- Avoid plastic clipboards, binders or hard covers.
- Collect samples for PFAS first before any other samples collected since containers for other methods might have PFAS present.



BOTTLES

For each set of samples being collected, Microbac has provided the following:

- (2 ea) 500 ml sample bottles unpreserved. These are your sample containers.

A sample set is composed of samples collected from the same site/location at the same time.

EPA 1633 PFAS SAMPLE COLLECTION GUIDE: COLLECTION PROCEDURE

01

WASH HANDS

Sampler must wash hands before wearing nitrile gloves to limit contamination during sampling.

02

COLLECT THE ENVIRONMENTAL SAMPLES

- All sample collection tools should be PFAS free (HDPE or Polypropylene, stainless steel) Fill bottles to the shoulder, making sure not to overfill containers.
- Close containers securely. Indicate sampling date, time and site on the bottle labels and Chain of Custody.

03

PLACE BOTTLES IN COOLER

Place all bottles in a cooler filled with ice (NO blue ice packs allowed) and return to the laboratory.
Hold time is 28 days.



CHAIN OF CUSTODY FORM

The COC is used to document the Sample ID: Container ID relationship. Complete the COC information making certain to maintain the relationship between the Container ID and the Sample ID as described in step 2 of the Collection Procedure above.